



Exterpark Decking Users' Guidelines

Fastening Hardwood to substructure

Plus Hardwood and Classic Hardwood Range

Do not screw through the deck, only use the clips designed for this application

These boards can be screwed through the fastening clips only purchased with the decking. Following extensive trials we recommend and supply the best stainless screws which should be used.

Joist Spacing

Joist spacing of 400mm centres is recommended for normal residential use (1.5 Kn/sqm) and 300mm for Commercial (4 Kn/sqm)

We endorse TRADA joist span charts and deck span tables when designing a decking structure. We would also recommend the use of a structural design engineer to advise upon the more complex decking designs, raised decks, balconies and bridges.

A minimum of three joists are required for our boards.

Cutting Exterpark hardwood decking

Should you need to cut the decking boards a sharp wood saw must be used; Oil should be applied to 'end grain', this can be supplied and is recommended. Always use current health and safety techniques when cutting any boards, wear eye protection and use a face mask to avoid the inhalation of dust.

Finishing

Our boards do not need sanding, they already have been. Simply apply hardwood decking oil with a roller (recommended) or paint brush or cloth

Troubleshooting

Whatever your problem or query please contact us at www.ExteriorDecking.co.uk and we'll answer you with the correct technical advice where ever possible.